

## AXLE NUT SOCKET SET

- \* Chrome molybdenum steel,
- \* 1/2" Drive
- \* Extra long socket makes full contact with axle nut
- \* Prevents slippage and distortion of axle nuts

### Parts List (w/ Sockets Description.)

**7863-07**  
38mm For ROVER  
ALLEGRO, METRO,  
MINI 1100, 1300  
FLYWHEEL NUTS  
& B BALL JOINTS

**7863-06**  
36mm For GM  
"E" style cars

**7863-05**  
35mm Late  
model GM

**7863-04**  
34mm Late  
model Buick,  
Cadillac,  
Chevy,  
Oldsmobile &  
Pontiac cars

**7863-03**  
32mm Late  
model FWD  
Honda & FWD  
Chrysler cars

**7863-02**  
30mm For GM "X", "J"  
and "A" style cars

**7863-01**  
29mm Late model GM,  
Ford Escort, Fiesta

