

Model # 7898

UNDERCAR KITS



Deluxe Noid Lite and GM AC Signal Test Lights Set



FEATURES:

- Economic way to check electronic fuel injection (EFI) signals
- Quickly and easily checks for systems of GM TBI, Bosch PFI Ford TBI, GM PFI, Geo TBI and GM SCPI
- To test, just disconnect the fuel injectors, plug the Noid Lite into injector wiring harness then crank the engine
- Normal voltage is indicated by flashing light which is visible from passenger compartment
- Blow molded case for easy storage and transport

SALES AND MARKETING

401 S. PARK AVENUE
MONTEBELLO, CA 90640
(800) 221-9705

Phone: (323) 510-2950 • Fax: (323) 887-1958

WAREHOUSE AND OPERATIONS

372 OLD US HIGHWAY 52 SOUTH
MT. AIRY, NC 27030
(800) 221-9705

Phone: (336) 786-6432 • Fax: (336) 786-4992

E-mail : astrotools@astrotools.com

WEBSITE : www.astrotools.com