



Model # 9512

**THE GRABBER -
CLAMPING
VALVE CORE
REMOVAL TOOL**

SALES AND MARKETING
2417 SEAMAN AVENUE
SOUTH EL MONTE, CA 91733
Phone: (800) 221-9705
USA Toll Free
Fax: (877) 318-2194
Phone: (626) 228-3170
Fax: (626) 228-3124

372 OLD US HIGHWAY
52 SOUTH
MT. AIRY, NC 27030
(800) 221-9705
Phone: (336) 786-6432
Fax: (336) 786-4992




Astro

E-mail : astrotools@astrotools.com
WEBSITE : www.astrotools.com



SHOP EQUIPMENT

UNDERCAR KIT HYDRAULICS HAND TOOLS AIR TOOLS



**MADE FROM
STAINLESS STEEL**

**EXTENDABLE
COLLET CLAMP**



- Step 1** Press and hold down the top cap of The Grabber.
- Step 2** Slide the extended collet over the ball end of the valve core and release.
- Step 3** Seat The Grabber fully into the valve stem and lock the jaws onto the valve core.
- Step 4** Rotate The Grabber counter-clockwise to unthread the valve-core.
- Step 5** Place The Grabber with the now attached valve core aside (or clip to your pocket for convenience) while performing the task at hand.

Model	Length	Material
9512	75mm	STAINLESS STEEL

- **Extendable collet securely clamps onto valve cores**
- **Valve core remains in the jaws of the tool once unscrewed**
- **No more fumbling with valve cores when installing or removing**
- **No more searching for lost valve cores**
- **Works on nearly all automotive and industrial valve cores**